ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver & Hammer (not provider).

| PART LIST | | | |
|-----------|----------------------|-------|--|
| ITEM | DESCRIPTION | QTY | |
| Α | HEADBOARD | 1 PC | |
| В | HEADBOARD WING (L&R) | 2 PCS | |
| С | HEADBOARD SUPPORT | 1 PC | |
| D | FOOTBOARD | 1 PC | |
| Е | SIDE RAIL (L&R) | 2 PCS | |
| F | CENTER RAIL | 1 PC | |
| G | CENTER SUPPORT LEG | 3 PCS | |
| Η | LEG | 4 PCS | |
| I | BED SLAT | 1 SET | |
| J | SIDE RAIL SUPPORT | 2 PCS | |

| HARDWARE LIST | | | |
|---------------|---------------------------|--|--------|
| ITEM | DESCRIPTION | | QTY |
| 1 | JCBC BOLT M6 x 45mm | ((((((((((((((((((((((((((((((((((((((| 18 PCS |
| 2 | JCBB BOLT M8 x 50mm | | 16 PCS |
| 3 | M6 SPRING WASHER | 0 | 10 PCS |
| 4 | M6 FLAT WASHER | | 8 PCS |
| 5 | M8 SPRING WASHER | 0 | 16 PCS |
| 6 | WOOD DOWEL M8 x 30mm | | 4 PCS |
| 7 | WOOD DOWEL M10 x 30mm | | 8 PCS |
| 8 | M4 ALLEN KEY (BALL SHAPE) | ſ | 1 PC |
| 9 | M5 ALLEN KEY (BALL SHAPE) | | 1 PC |
| 10 | WOOD SCREW M4 x 38mm | | 9 PCS |
| 11 | M8 FLAT WASHER | 0 | 16 PCS |







