## **ASSEMBLY INSTRUCTIONS**

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver & Hammer (not provider).

PART LIST			
ITEM	DESCRIPTION	QTY	
A	HEADBOARD	1 PC	
В	FOOTBOARD	1 PC	
C	SIDE RAIL	2 PCS	
D	CENTER RAIL	1 PC	
E	CENTER SUPPORT	2 PCS	
F	CENTER SUPPORT LEG	3 PCS	
G	BED SLAT	26 PCS	
Н	BED LEG	4 PCS	
I	HEADBOARD WINGS (L&R)	2 PCS	
J	HEADBOARD SUPPORT LEG	2 PCS	

HARDWARE LIST			
DESCRIPTION		QTY	
JCBB BOLT M8 x 45mm	<b>@</b>	14 PCS	
M8 FLAT WASHER	0	14 PCS	
M8 SPRING WASHER		14 PCS	
PVC BLACK WASHER		6 PCS	
BED SLAT SIDE FITTER		26 PCS	
BED SLAT CENTER FITTER	$\Diamond$	13 PCS	
WOOD DOWEL M10 x 30mm		4 PCS	
WOOD SCREW M3.5 x 16mm	<b>40000</b>	8 PCS	
WOOD SCREW M4 x 20mm	<b>&lt;====</b> €	2 PCS	
M5 ALLEN KEY (BALL SHAPE)	Ĵ	1 PC	
	DESCRIPTION  JCBB BOLT M8 x 45mm  M8 FLAT WASHER  M8 SPRING WASHER  PVC BLACK WASHER  BED SLAT SIDE FITTER  BED SLAT CENTER FITTER  WOOD DOWEL M10 x 30mm  WOOD SCREW M3.5 x 16mm  WOOD SCREW M4 x 20mm	DESCRIPTION  JCBB BOLT M8 x 45mm  M8 FLAT WASHER  M8 SPRING WASHER  PVC BLACK WASHER  BED SLAT SIDE FITTER  BED SLAT CENTER FITTER  WOOD DOWEL M10 x 30mm  WOOD SCREW M3.5 x 16mm  WOOD SCREW M4 x 20mm	







