

NO	HARDWARE PACK ( FOR TABLE )		QTY
A	JCBC Screw M6 x 55mm	<b>(</b>	6
В	Barrel Nut		6
C	Wood Button	$\bigcirc$	6
D	Allen Key M4		1

NO	HARDWARE PACK ( FOR STOOL )		QTY
Е	JCBC BOLT M6 x 45mm	0	8
F	CSK CB Screw M4 X 32mm		16
G	Flat Washer	0	8
Н	Spring Washer		8

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched .
- Check to be sure that you have all parts and hardware .
- Remove all wrapping materials, including packing straps before you start to assemble.





