

SW 8029 - F / Q / K

1. Attach the headboard post (P1) to the headboard (P2). You will need to use hardware:

- A = 4pcs
- D = 4pcs
- E = 8pcs

2. Attach the side rail (P3) to the headboard (P2) and footboard (P4) using hardware:

- B = 8pcs
- D = 8pcs
- E = 4pcs
- F = 8pcs

3. Fix the adjuster (I) to the support leg (P6) using hardware:

- I = 2pcs

Attach the support legs (P6) to the centre rail (P5) and footboard (P4) using hardware:

- C = 2pcs

Attach the centre rail (P5) to the headboard (P2) and footboard (P4) using hardware:

- G = 2pcs

4. Lay the slats (P7) between the side rail (P3) using hardware:

- G = 28pcs (F) or
- G = 30pcs (Q/K)








Attach the slats (P7) to the centre rail (P5) using hardware:

- G = 3pcs










WARNING!!

- Remove hardware from box and sort by size.
- Please check to see that hardware and parts are present prior start of assembly.
- Please follow attached instruction in the same sequence numbered to ensure fast and easy assembly.
- Do not use this bed if any part is broken, torn or missing.
- The assembly of this product requires two people.
- Do not use any power tools as this may damage the frame and will invalidate any claim.

PART LIST

	Headboard Post = 2pcs
	Headboard = 1pcs
	Side Rail = 2pcs
	Footboard = 1pcs
	Centre Rail = 1pcs
	Support leg = 2pcs
	Bed Slats (F) = 14pcs Bed Slats (Q/K) = 15pcs

HARDWARE LIST

	M6 x 100mm JCBC	4pcs
	M6 x 60mm JCBC	8pcs
	M6 x 50mm JCBC	2pcs
	BARREL NUT	12pcs
	Ø8 x 35mm WOOD DOWEL	12pcs
	WOODEN PLUG	12pcs
	M4 X 25mm SCREW (F) M4 X 25mm SCREW (Q/K)	33pcs 35pcs
	ALLEN KEY M4	1pcs
	ADJUSTER	2pcs

