## **ASSEMBLY INSTRUCTIONS**

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS: 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.

2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

3. Keep all hardware parts out of reach of children.

HEAD FOOT SIDE CENT	Н	G	וד ה	Э	g	C	8	А	<u>-</u>
BOARD BOARD BOARD RAIL ER RAIL ER SUPPORT LEG LAT LAT EG	BED LEG	BED SLAT	CENTER SUPPORT LEG	CENTER SUPPORT	CENTER RAIL	SIDE RAIL	FOOTBOARD	HEADBOARD	DESCRIPTION
1 PC 2 PCS 2 PCS 1 PC 2 PCS 3 PCS 3 PCS 4 PCS	4 PCS	24 PCS	3 PCS	2 PCS	1 PC	2 PCS	1 PC	1 PC	113

RT LIST			PART LIST		
CRIPTION	QTY	ITEM	DESCRIPTION		QTY
)ARD	1 PC	-	JCBB BOLT M8 x 30mm	~	8 PCS
)ARD	1 PC	2	WOOD SCREW M3.5 x 16mm	1	8 PCS
VIL.	2 PCS	ω		Ø	24 PGS
RAIL	1 PC		ᅜ	V	12 PGS
CI PROPT	300	4		K	
SUPPORT	2 PCS	п	ME ALLEN VEV		3
	3	ú			(

