









ASSEMBLY INSTRUCTION

Model: 2461S

			Chaise	Sofa
A	Plastic Legs		5pcs	4 pcs
B	Washer		5pcs	4 pcs
C	Bolt	 Φ8mm x70mm	5 pcs	4pcs
D	Allen key		1 pc	1 pc
E	Center leg	 Φ60mm x70mm	N/A	1 pc
F	Washer		N/A	1 pc



U2461S-60R / 60L Sofa



U2461S-70L / 70R Chaise

