
















**MODEL : SE TV 90131WI-CLB/DG**

**PANEL POSITION**





	ACCESSORIES	QUANTITY
A	 MINIFIX M5 x 24MM	12 PCS
B	 MINIFIX CASING	12 PCS
C	 WOOD DOWEL M8 x 30MM	6 PCS
D	 IRON SHELF SUPPORT	12 PCS
E	 SCREW M6 x 50MM	24 PCS
F	 PVC SQUARE KNOB (BLACK) SCREW M4 x 25MM	2 PCS 2 PCS
G	 STOPPER INSERT	2 PCS
H	 HINGES 7/8" SCREW M3.5 x 16MM	4 PCS 24 PCS
I	 ROUND TAPER LEG SCREW M3.5 x 16MM	6 PCS 24 PCS
J	 POWER PIN	30 PCS
K	 ALLEN KEY	1 PC






START ASSEMBLY


STEP 1




A  
8 PCS



C  
2 PCS





G  
2 PCS




B  
4 PCS


STEP 2




B  
4 PCS



A  
4 PCS





C  
2 PCS




D  
12 PCS


STEP 3



C  
2 PCS





B  
4 PCS




H  
4 PCS

STEP 4




E  
4 PCS


**STEP 5**




**STEP 6**




**STEP 7**




**STEP 8**




**STEP 9**




**STEP 10**




**STEP 11**



**STEP 12**



**STEP 13**



**COMPLETED**

