



ASSEMBLY INSTRUCTION

MODEL : TV 834180

DESCRIPTION : TV CABINET

HARDWARE

A WOOD DOWEL 8 X 25 1X20	B 16MM CB SCREW M3.5X16MM 1X56	C 38MM CB SCREW M4X38MM 1X12	D 65MM CB SCREW M4X65MM 1X8	E NAIL 5/8 1X30	F ALLEN KEY 1X1	G G1 G2 G3 MINIFIX 5654+5546 QUICKFIT CAP 6 SETS	H METAL SHELF SUPPORT 5X16 1X8	I MIRROR BRACKET 1X8	J J1 J2 K455 ROLLER 4 SETS	K HANDLE BK-118-35 (METAL) 1X1	L L1 L2 DRAWER SLIDE 12" 1 SET	M 2.5" PVC LEG 1X5
--	---	---	--	----------------------------------	----------------------------------	---	--	--	---	---	--	--

