







Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS : 1. Do not FULLY - TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
2. Do not OVER - TIGHTEN the nut or bolt to avoid causing damages to the thread.
3. Keep all hardware parts out of reach of children.


NOTE : THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed : Screwdriver (not provider).

PART LIST			
ITEM	DESCRIPTION	BOX	QTY
A	HEADBOARD	1	1 PC
B	FOOTBOARD	2	1 PC
C	SIDE RAIL	2	2 PCS
D	CENTER RAIL	2	1 PC
E	CENTER SUPPORT LEG	2	3 PCS
F	BED SLAT	1	1 SET
G	BED LEG	3	2 PCS


HARDWARE LIST (BOX : 2)		
ITEM	DESCRIPTION	QTY
1	JCBB BOLT M8 x 30mm 	16 PCS
2	M8 FLAT WASHER 	16 PCS
3	M8 SPRING WASHER 	16 PCS
4	WOOD SCREW M4 X 20mm 	2 PCS
5	WOOD SCREW M4 X 38mm 	9 PCS
6	M5 ALLEN KEY (BALL SHAPE) 	1 PC

STEP 1



Loosen the pre-inserted bolt on the headboard and footboard using Allen key ball shape (6).


STEP 2




ASSEMBLY INSTRUCTIONS

2 OF 3


STEP 3



STEP 4




STEP 5




ASSEMBLY INSTRUCTIONS

3 OF 3

STEP 6



STEP 7



*** When moving the bed position, the center support legs must be adjust to be straight to avoid any broken problem.**